



Product Specification for GroundSmart™ 16" SmartLoc™ Pavers

Product Information

| | |
|------------------|--|
| Description | GroundSmart™ 16" SmartLoc Pavers |
| Sizes/Weights | 16" L x 16" W x 0.625" H, approx. 5.45 lbs |
| Colors Available | Black, Brown, Gray and Red |
| Composition | Recycled rubber, polyurethane binder, colorant |

Installation

1. Thoroughly clean the surface where the pavers are to be installed. Allow to dry completely.
Ensure that both the paver and surface have no moisture for best adhesion.
2. Place the GroundSmart paver on the surface to ensure you have the proper amount and that you like the overall design.
3. To achieve the best results, snap chalk lines as a guide, and the pavers will be straight during installation.
4. Begin installation in a corner or against a wall and work in a small section.
5. Apply a polyurethane adhesive to the bottom of the paver and place it on the surface.
6. Once the adhesive is applied, connect adjoining pavers together to ensure a secure fit. Gently tap pavers into place with a rubber mallet for adhesion.
7. Continue laying full pavers in place until complete.
8. For any pavers that require cutting, use a razor knife, cutting the paver in a series of scores to acquire a clean edge. Always wear work gloves and safety goggles when cutting materials.
9. Allow area to dry for a minimum of 24 hours before use.
10. After installation some natural weathering of pavers may occur.

Note: If attaching pavers to a wood surface you may also use a one-inch staple in place of polyurethane adhesive. Manufacturer does not recommend installing pavers over a sand, loose rock or dirt base.